


**6**  
**G**



000238-003

## FE290 STARTER/GENERATOR MOUNTING

ITEM	PART NO.	DESCRIPTION	QTY
		1 2 3 4	
1	1012830	Screw, M8-125 X 22 Hex-Head .....	2
2	101524001	Bracket, Starter/Generator Mounting (FE290) .....	1
3	1015920	Ground Wire Assembly .....	1
4	1015932	Bolt, Carriage, 5/16-18 .....	1
5	1016074	Screw, M8-1.25 X 18mm Torx .....	1
6	1016883	Bracket, Starter/Generator Adjustment .....	1
7	101837301	Wire Assy, #6 Green .....	1
8	101916701	V-Belt .....	1
9	1241	Washer, 5/16 Type A Flat .....	1
10	1242	Nut, 5/16-18 Hex .....	1
11	705	Screw, Cap-hex Hd 3/8-16x1.25 .....	2
12	7173	Screw, 5/16-18 X 0.75 Hex-Head Cap .....	1
13	7174	Lockwasher, 5/16 Split .....	3
14	7473	Locknut, 5/16-18 Nylon Insert .....	1
15	8754	Locknut, 3/8-16 Hex .....	2

6

G