


ELECTRICAL 2



Ref. No.	Part Number	Description	Qty	Remarks
28	1E6-82151-00-00	. FUSE (10A)	2	
29	90464-12036-00	CLAMP	2	
30	J55-82510-00-00	MAIN SWITCH ASSEMBLY	1	
31	J17-82511-20-00	. KEY, MAIN SWITCH	1	
32	J41-82550-01-00	ENGINE STOP SWITCH ASSEMBLY	1	
33	J38-82617-00-00	SWITCH	1	
34	98511-04025-00	SCREW, PAN HEAD	1	
35	92990-04100-00	WASHER, SPRING	1	
36	92901-04600-00	WASHER, PLATE	1	
37	JH2-85720-00-00	OIL LEVEL GAUGE ASSEMBLY (JF2-85720-00-00)	1	
38	97011-06020-00	BOLT	2	
39	92995-06100-00	WASHER, SPRING	2	
40	92990-06600-00	WASHER, PLATE	2	
41	J38-82598-00-00	GROMMET	1	
42	J10-83383-02-00	BUZZER	1	
43	97313-06016-00	BOLT, HEXAGON	1	
44	92995-06100-00	WASHER, SPRING	1	
45	92990-06600-00	WASHER, PLATE	1	
46	95702-06600-00	NUT, FLANGE	1	
47	70R-83530-00-00	PILOT LIGHT ASSEMBLY	1	
48	123-83516-21-00	. BULB (12V-3.4W)	1	
49	*---	FRONT WHEEL ASSEMBLY	1	LM (SEE NOTE)
6-1	90108-06420-00	BOLT, BATTERY CABLE	1	
6-2	92801-06000-00	NUT, BATTERY CABLE	1	
8-1	90108-06420-00	BOLT, BATTERY CABLE	1	
8-2	92801-06000-00	NUT, BATTERY CABLE	1	
32-1	JF2-82532-00-00	. CAP, RUBBER	1	

